



## Western Washington Repeater Association

PO Box 1001, Silverdale, WA 98383-1001

<http://www.wv7ra.org>

146.620MHz and 442.650MHz pl 103.5Hz

Cut Out - Laminate  
Keep Posted

### WW7RA AUTO-PATCH PROCEDURES

**WARNING: YOU MUST HAVE A GOOD SOLID SIGNAL  
FOR THE REPEATER TO HEAR YOUR TONE DIGITS!**

- 1) To initiate an auto patch call:  
Press the PTT and transmit " this is {Your Call Sign} accessing the WW7RA auto patch".
- A) **Without speed dial:**
  - 1) Keep the PTT depressed and immediately punch in on the keypad \*74 to bring up the dial tone.
  - 2) Release the PTT and listen for a dial tone.
  - 3) After hearing a dial tone, press the PTT and keypad in the seven-digit phone number you wish to call.
  - 4) Release the PTT and listen for answer.
- B) **Using speed dial:**
  - 1) Keep the PTT depressed and immediately punch in on the keypad your personal four digit speed dial number, DO **NOT** USE \*74 or this procedure.
  - 2) Release the PTT and listen for telephone ringing and an answer.
- C) **In both cases, after the party answers, consider advising them that you are on a radio.**
- 2) **To terminate an auto patch call:**
  - A) For all calls, with or without speed dial
    - 1) Press the PTT and punch in "#" to hang-up.
    - 2) Release the PTT. The system will announce "Auto Patch Clear".
    - 3) Press the PTT and transmit " this is {Your Call Sign} complete with WW7RA auto patch."
    - 4) Release the PTT.